

RESIDUAL RISK ASSESMENT WHEREVER POSSIBLE, RISK IS DESIGNED-OUT OF THIS PROJECT DURING THE DESIGN PROCESS. WHERE THIS IS NOT POSSIBLE, THE RISK WILL BE MINIMISED AND ANY RESIDUAL RISK WILL BE NOTED AND INDICATED BY THE SPECIAL CARE IS TO BE TAKEN WHEN WORK AT HEIGHTS IS IN I. SPECIAL CARE IS TO BE TAKEN WHEN WORN AT HEIGHTS IS IN PROGRESS. APPROPRIATE EDGE PROTECTION IS TO BE PROVIDED. MATERIALS, FORMWORK MEMBERS OR ANY OBJECTS ARE NOT TO BE STACKED AGAINST THE EDGE PROTECTION. SITE TEAM ARE TO ONSIDER THE RISK OF FALLS FROM HEIGHT WHILST INSTALLING ISMANTLING AND MAINTAINING THE SUPPORT SYSTEM AND EDGE . ALL LIFTING OPERATIONS ARE TO BE CONDUCTED BY COMPETEN PERSONNEL ONLY. ALL LIFTING EQUIPMENT IS TO BE INSPECTED BEFORE COMMENCING WORKS AND CLASSIFIED AS SAFE TO USE. PECIAL CARE IS TO BE TAKEN WHEN LIFTING OPERATIONS ARE ERFORMED AND EQUIPMENT IS TO BE TRANSPORTED OVER THE /ORKING AREAS. ALL GROUND PERSONNEL IS TO BE MADE AWARE HAT LIFTING OPERATIONS ARE TAKING PLACE. . REGULAR INSPECTIONS ARE REQUIRED TO ENSURE INTEGRITY OF THE SYSTEM IS MAINTAINED. ANY DAMAGED PARTS SHOULD BE REPLACED AT THE EARLIEST OPPORTUNITY. IF HAZARD IS NOTICE! T MUST BE REPORTED TO THE SUPERVISOR IMMEDIATELY. FOLLOW POUR RATES INDICATED ON THE DRAWING WITH ATTENTION TO THE MAX. DESIGN PRESSURE AND THE RATE OF RISE MAKE SURE CONCRETE STRENGTH IS SUFFICIENT TO SUPPORT ITS OWN WEIGHT BEFORE STRIKING THE FORMWORK.

400 STOP-ENDS [DESIGNED BY CLIENT] 18MM PLYWOOD









IMPORTANT:

CONSULT YOUR TEMPORARY WORKS DEPARTMENT BEFORE USING THIS DESIGN FOR CONSTRUCTION.



IMPORTANT:

TIGHTEN ALL TENSILE BOLTS WITH AN 18V IMPACT WRENCH !!! TIGHTEN ALL CONCRETE BOLTS WITH A 110V IMPACT WRENCH !!!



CONCRETE

IMPORTANT:

COSTUMER IS TO ENSURE THAT DURING POUR OPERATIONS CONCRETE IS PLACED IN AN EVEN MANNER PREVENTING THE IMBALANCE OF ANY FORCES. CONCRETE PLACEMENT IS TO BE CONTROLLED TO AVOID ADVERSE FORCES FROM HEAPING, SURGE AND IMPACT.



IMPORTANT:

ALL CONCRETE HOLDING DOWN BOLTS TO BE INSTALLED ACCORDING TO THE MANUFACTURER TECHNICAL APPROVAL AND INSTALLATION GUIDES AND INTO STRUCTURALLY SOUND CONCRETE TO ENSURE A SECURE FIXING.

EVISION	DATE	DESCRIPTION	SIGNED
0	4/06/15	ORIGINAL VERSION	K.P.
С	4/06/18	ANNUAL REVISION	T.F.

IMPORTANT NOTES:

ALL DIMENSIONS IN MILLIMETRES UNLESS NOTED

MINIMUM THICKNESS AND STRENGTH OF CONCRETE

WITH A IIOV IMPACT WRENCH!

THE BRACKETS.

WITH 25MM WOOD SCREWS.

BLINDING FOR INSTALLATION OF CONCRETE BOLTS IS

ALL TENSILE BOLTS TO BE TIGHTENED WITH AN 18V

SPECIFIED IN THE MANUFACTURER'S TECHNICAL APPROVAL

AND INSTALLATION GUIDES. ALL BOLTS TO BE TIGHTENED

PLYWOOD TO BE MIN. 18MM EXTERIOR STRUCTURAL GRADE

POSITION THE PLYWOOD JOINTS TO FALL ON CENTRE OF

PLYWOOD TO BE FIXED TO THE BRACKETS FROM THE BACK

APPLY CONCRETE RELEASE AGENT / MOULD OIL TO FACE

ALL TIMBER MEMBERS TO BE PROVIDED BY CLIENT.

BRACKETS TO BE AT MAX. 400MM CENTRES.

OF PLYWOOD PRIOR TO POURING CONCRETE.



Fast-Form www.fastformsystems.com info@fastformsystems.com

Tel South: 00 44 (0) 0203 507 1832 / 507 1833 / 507 1834

Tel North: 00 44 (0) 1472 488230 / 488660 / 485640



Head Office: Unit 1 Estate Road 6 Grimsby N.E.Lincs **DN31 2TG**

LEGAL NOTICE:

Fast Form ™ is the Trade Mark of Fast-Form Systems Ltd and all designs are copyright and intellectual property of Fast-Form Systems Omega Business Park Ltd and may not be reproduced or used without permission. Fast Form ™ is covered by the following Patents: granted GB2508263 / GB2533172 Patents Pending GB 1616005.3 / GB 1506126.0 / US-2016-0194887 / PCT W02016 / 110663 / EP 14780541.0 / PCT GB2014 / 052586. Copyright or Trade Mark infringements will be prosecuted, If you see any similar bracket in operation without our name on it please send us an email to info@fastformsystems.com we offer a reward for all successful prosecutions.

Orawn	by:	Karol	Podsiadlo	Da

ate: 4/06/15 | Rev: C

Size:

Designed by: K. Podsiadlo Drawing no: FFS-BS1200W

Project: Fast Form Bracket System

Drawing title: 1.2m Bracket System Wall